



Ohio Two Cylinder Club Inc.
Eastern National Expo XI
 at Wayne County Fairgrounds, Wooster, Ohio



Classic Class Tractor Pull Rules - John Deere Only - Up to 1973

Friday, June 17, 2022

Fun Pull - \$15 per hook. You must display / show in order to pull.

1. Any tractor or puller found to be unsafe or illegal might be disqualified or barred from hooking. **No** alcoholic beverages will be permitted.
2. Drivers must stay on the seat of the tractor at all times.
3. Any part falling off the tractor after being hooked, and until the tractor is unhooked, will result in disqualification.
4. When starting engines, operator must be in the seat. Starting engines while standing on the ground is prohibited, except for hand crank engines.
5. Unattended tractors with the engines running are prohibited. These rules apply to the pit area, staging area, track area, and ALL show ground areas.
6. **Age** - Those under 18 years of age must have a written parental/guardian permission.
7. Two hooks per class. One trophy per tractor.
8. **Entry** - A tractor cannot be entered in classes below its manufactured shipping weight.
9. **Speed** - Any gear, not to exceed 2.5 MPH.
10. Speed exceeding the limit and sounding the horn three times will result in disqualification for that hook. A driver may stop once before the 50-foot cone and allowed a restart.
11. **Weights** - Weights of a bolt-on type to either the front or the back wheels only. Factory Front's are allowed if they are made for that tractor.
12. Stock plus 10% RPM. Distributors can be used on Antique tractor.
13. **Hitches** - Maximum 18" height. Hitches must be as from factory – unaltered for that specific tractor. Operator must furnish a clevis with a minimum opening of 2.5 inches. Hitch measured at hook point of clevis. All tractors must pull from an original draw bar hooked to the original belly hook point.
14. **Safety** - The front wheels of the tractor are not to exceed 16 inches (or be declared unsafe by the flagman) off the ground during a pull.
15. **Kill Switches** - Kill switches are mandatory. We will have some temporary switches available to use. If you are a puller, please put your own on.
16. **Appearance** - Tractors must maintain original stock appearance. No homemade rear end / PTO covers allowed.
17. **Tires** - No alterations permitted. 15.5 x 38 – 18.4 x 38 – 7500# and 8500# class.
18. **Exhibition Puller** - Any show participant who has a pure stock tractor that does not comply with the rules or does not have enough tractors to qualify in weight class may pull Exhibition. Paid entry fee required. Tractor cannot place in a class. Exhibition tractors will be the last pullers in the class.

Classic Weight Classes

3000# 3500# 4000# 4500# 5000#
 5500# Powder Puff 5500# 6500#
 7500# 8500#
 Open Class – up to 10,000#

Div. II Tractor Pull Rules - John Deere Only - Up to 1973

1. Maximum tire size 15.5 inches, 7500# 18.4 x 38 inches.
2. Cut tires permitted in all classes.
3. No RPM limit (unchecked).
4. Maximum 4.0 MPH with speedometer on sled.
5. Stationary draw bar 18 inch height maximum, 18 inch back from center of rear wheel minimum.
6. Kill switches are mandatory. Wheelie bars are recommended.
7. Speed exceeding the limit and sounding the horn 3 times will result in disqualification for that hook. A driver may stop once before the 50 ft. cone and allowed a restart.
8. **Safety** - The front wheels of the tractor are not allowed to exceed 16 inches (or be declared unsafe by the flagman) off the ground during a pull.

Div. II Weight Classes

4500# 5500# 6500# 7500#

Weight Class Pulling Order

	<u>Classic</u>	<u>Div. II</u>
1.	3000 #	
2.	3500 #	
3.	4000 #	
4.	4500 #	
5.	4500 #
6.	5000 #	
7.	5500 #	
8.	5500 # Powder Puff	
9.	5500 #
10.	6500 #	
11.	6500 #
12.	7500 #	
13.	7500 #
14.	8500 #	
15.	Open Class	

- Line-up is in order of sign-up.
- If you are not in line when you are called, you will pull last in class.

For more information, contact David Howman at 330-466-0197 or Ted Payn at 248-765-5464.